


Installing CompactFlash cards


Up to two CompactFlash cards can be installed to add additional fonts to the printer.

To install a CompactFlash card


1. Turn the printer power off.




2. Unplug the power cord and disconnect any cables.




3. Grasp the cover on the right side of the printer and pull it firmly toward the rear of the printer until it stops.




4. Remove the cover from the printer.




5. Open the access door by pulling on the metal tab.




6. Remove the CompactFlash card from its package.




7. Hold the CompactFlash card by its edges and line up the grooves in the side of the card with the tabs in the CompactFlash card slot.




8. Slide the CompactFlash card into place.




9. Close the access door, press firmly until it snaps into place.



10. Set the bottom of the cover onto the printer. Make sure the bottom tab on the cover fits into the corresponding slot in the printer. Rotate the cover up, toward the printer.



11. Slide the cover toward the front of the printer until it clicks into place.



12. Reattach any cables and the power cord, then turn the printer power on and test the installation. (See [Checking memory installation](#).)

Use Device Storage Manager in HP Web Jetadmin to manage fonts. For more information, see the Help in HP Web Jetadmin.